VOLVO BM 616 B/646



Specification Volvo BM Loader 616B/646

PRODUCTIVE

The 616B and 646 give the choice of 2- or 4-wheel drive, differential lock, large wheels and good weight distribution, all of which give these machines the qualities for efficient operation in general construction and roadworks, cross-country power line erection, plus all trenching and ditching duties.

RELIABLE

Mounted on Volvo BM's well proven loader chassis, giving extensive component co-ordination, the 616B and 646 are sturdy and reliable both in quality and performance.

ECONOMICAL

The machines' versatility is due to their off-road mobility and to the availability of a wide range of attachments. These factors make the 616B and 646 efficient specialist machines for a wide variety of jobs.



Output

SAE J 270 Br. Max. torque SAE J 270 Br. Bore Stroke

No. of cylinders Displacement

646 616B

Volvo BM TD42 Volvo BM D42 59 kW at 38 rev/s 63 kW at 38 rev/s (62 kW as per SAE J 316)

299 Nm at 27 rev/s 265 Nm at 25 rev/s (269 Nm as per SAE J 816)

105.57 mm (4.156 in) 120 mm (4.724 in)

1

4.2 litres (256 ln3)

ENGINE

The D42 is a 4-cylinder direct-injection 4-stroke diesel engine, with overhead valves and replaceable wet cylinder linings, plus a balancing unit for vibrationless operation.

The engine's air-intake cleaning system is of the 2-stage type.

- 1. Precleaner of cyclone type.
- 2. Cyclone cleaner with paper filter and catch-all filter.
- 3. Indicator lamp on instrument panel warns when filter should be cleaned or replaced.



ELECTRICAL SYSTEM

Voltage 43 A (1200 W) Alternator Two, 12 V and 96 Ah Battery 3 kW (4 hp) Starter Motor

The batteries are located on the right-hand side of the machine behind a lockable security door. The well-protected fuses are mounted in two boxes to the left and in front of the cab instrument panel.



TORQUE CONVERTER

Single-stage converter with free-wheel stator.

Torque ratio 3.65:1.



Speeds forward and reverse

TRANSMISSION

Volvo BM hydromechanical gearbox with power shift.

Max. speeds with 18.4-34/14 tyres

1. ~ 4.5 mph (7 km/h)

2. ~ 7.5 mph (12 km/h)

3. ~ 12 mph (19 km/h)

4. ~ 19 mph (30 km/h)

The Volvo BM transmission has two forward gears and two reverse in one low and one high gear range.



AXLES

Type Volvo BM

Drive axle with final drives in central final drive housing.

Differential lock type Volvo BM

616B: Front axle: box construction with 28° oscillation.

646: Front axle: drive axle with differential, sealed spherical steering joints and planetary type hub reduction. Drive shafts are fully floating. The motive power is transmitted from the hydraulic gearbox and dropbox via the propeller shaft. Front axle oscillation 20°.



BRAKES

Fully enclosed disc brakes, located before the final drives. Hydraulic operation by foot pedal. Steering brake operated by lever

with automatic return selector valve. Parking brake: mechanically operated by lever.



TYRES

616B	front	12.5-20/10
		14.5-20/10
	rear	18.4-34/14
	**	18.4-30/12
646	front	14.9-24/14
	rear	18.4-34/14



Pump Pump capacity

Operating pressure

STEERING SYSTEM

Hydrostatic with twin cylinders on steering axle.

Gear pump 33 litres/min (7.3 UK gal/min) at 2300 rev/min 9 MPa (1300 lbf/in2)

The machine can still be steered in the event of a pressure loss.



Pump capacity Operating pressure

Oil tank volume Hydraulic system volume Oil filter

HYDRAULIC SYSTEM Common for loader and excavator unit

Gear pump 113 litres (25 UK gal) at 1775 rev/min Max, operating pressure 17 MPa (2465 lbf/in2) 110 litres (24 UK gal)

190 litres (42 UK gal) Full-flow filtration through filter cartridge with magnetic core.

Safety pressure relief valve located in loader valve; opening pressure 17 MPa (2465 lbf/in²).

There is a transport by-pass between the pump and the loader's control valve consisting of a flow regulator and selector valve. This limits the oil flow to 60 I/min (13 UK gal/min) when the transport gear is engaged. When the working gear is engaged for excavation, the capacity of the pump at 1775 rev/min is 113 I/min - 25 gal/min.

Hydraulic system - excavator


The control valve for the excavator unit incorporates a shock valve for the boom, excavating, slewing and bucket cylinders. A throttle check valve is connected to the piston-rod side of the boom and excavator cylinders. This limits the rate of descent, but allows full flow during lifting. The excavator unit is operated by two levers. Lateral angulation of the bucket arm is controlled by a foot pedal (left foot). The control valve has 7 functions: two outriggers, slew, boom, bucket arm, bucket and lateral angulation.


ore	Piston rod dia.	Stroke
00 mm	45 mm	366 mm
25 mm	60 mm	927 mm
25 mm	60 mm	845 mm
10 mm	60 mm	740 mm
10 mm	60 mm	250 mm
10 mm	60 mm	436 mm
	00 mm 25 mm 25 mm 10 mm 10 mm	rod dia. 00 mm 45 mm 25 mm 60 mm 25 mm 60 mm 40 mm 60 mm 40 mm 60 mm

Hydraulic system — loader

The loader is operated by a single lever located to the right of the operator's seat. The hydraulic system is double-acting: the loader can relieve the load on the front end during excavation work to maintain machine stability. The lifting arm is equipped with a bucket indicator to show the angle of the bucket in relation to the around. Third hydraulic function and single-acting lift function (float position) are available as optional extras.

Cylinder dimensions	Bore	Piston rod dia.	Stroke
Lift cylinders	110 mm	50 mm	525 mm
Tilt cylinders	100 mm	45 mm	366 mm





CAPACITIES



Cooling system Oil volume, engine Oil volume in gear box incl. converter Final drive and differential housing Fuel tank Hydraulic system Oil tank volume 646 differential housing

16 litres (28 UK pints) 10.5 litres (18 UK pints) 22 litres (39 UK pints) — at change 16 litres (28 UK pints)

50 litres (11 UK gal) 96 litres (21 UK gal) 190 litres (42 UK gal) 110 litres (24 UK gal) 6.0 litres (11 pints), planetary gear 2 x 5.0 litres (2×9 pints)



COMFORT

The operator is well protected. The robust cab has been approved in accordance with impact test specifications and is safe and roomy, with good visibility. The low

noise level provides a pleasant working environment especially desirable during long shifts.

The cab has a door on each side and an opening rear window. The right-hand door window can also be opened. The sun roof serves also as an emergency exit. As the cab is mounted on rubber pads, structure-borne noise and vibration transmitted through the chassis to the operator, is reduced to a low level. The operator's spring seat is equipped with a damping device. It is adjustable vertically, fore-and-aff and has an adjustable backrest. The driver can swivel the seat easily from a forward driving position to a rear-facing position for excavating. All instruments and controls are marked with symbols and located - according to frequency of use - within convenient reach and sight.



LOADER -**SPECIFICATION**

The snap-on coupling is of the same type as those fitted to the Volvo BM Allrounders, permitting use of 621/641 attachments (see attachment booklet).

Lifting force to top position 3.37 m (11 ft)	26 kN (5730 lbf)
Breakout force at bucket tip	41 kN kgf
	(9040 lbf)
Max. lifting height under flat bucket bottom	3.37 m (11 ft)
Max. clearance under tipped bucket	2.81 m (9.2 ft)
Distance between tipped bucket at top	
position and front of loader	0.67 m (2.2 ft)
Breakout angle	35°
Tipping angle at 2.44 m (8 ft) tipping height	45°



EXCAVATOR — SPECIFICATION

The cylinder attachment points have selfaligning sealed link bearings to eliminate

stresses and play. All hydraulic hoses have the same internal diameter and most of these are the same length, to simplify spare parts stocking. The bucket arm can be rotated continuously in relation to the boom. One cylinder, foot-operated, can rotate the bucket arm $\pm 30^{\circ}$. This rotating action can be utilised at any time during an excavation cycle. This design provides a number of advantages:

- you can dig along the foot of walls, fences etc.
- · you can dig ditches to the side of the machine
- you can do clean-up and exposing work around wells and

The machine is delivered with snap-on couplings as standard to facilitate bucket and attachment changes

Excavation depth	4.22 m (13.8 ft)
Reach	5.86 m (19.23 ft)
Loading height	3.77 m (12.37 ft)
Breakout force at bucket lip	5 000 kgf (11 000 lbf)
Excavating force at bucket lip	3 410 kgf (7 520 lbf)
Bucket volume rec.std.	380 litres (13.4 ft3)
Slew with laterally angled bucket arm	170 + 2 × 30°

Max. lifting force in

1000 kgf [2200 lbf] - boom cyl. hook (incl. bucket)

Max. lifting force in

1600 kgf (3530 lbf) - bucket arm cyl. hook (incl. bucket) 3.6 m (12 ft) wide with Parallel excavation

70 cm (28 in) wide bucket

STANDARD EQUIPMENT



ENGINE AND ELECTRICAL SYSTEM

Fuel gauge, battery partition Pilot lamp, indicator for air cleaner

Pilot lamp, driving and working

Pilot lamp, engine oil pressure

Engine temperature gauge Pilot lamp, parking brake Pilot lamp, charging Starter switch

Pilot lamp, rotating warning

beacon

STANDARD EQUIPMENT cont.



SAFETY AND COMFORT

Safety cab Interior rear-view mirror, 1 Exterior rear-view mirror, 2 Main headlights, bright/dim beams, 2 Working lights, forward, 2 Working lights, rear, 2 Parking/position lights, forward and rear, 2 Tail-lights and brake lights Direction indicators front and rear with hazard flasher Socket for inspection lamp Cigarette lighter Central warning lamp in excavating position for vital machine functions

Battery partition in cab Instrument lighting Cab lighting Lifting hook Ashtray Wipers for front and rear windows Protection plate under steering axle (616B) Instrument panel with: engine temperature gauge, hour counter, fuel gauge Tool box Transport braces (chains) for outriggers



TRANSMISSION

Differential lock

Pilot lamp, transmission temperature Pilot lamp, transmission oil pressure



HYDRAULIC SYSTEM

Pilot lamp for temperature of working hydraulics

Snap-on coupling for attachments on both excavator and loader

OPTIONAL EQUIPMENT

Underbody protection plates. front and middle Front fenders, 2 Cab ventilator with or without heating Air conditioning Float position valve for loader unit Third hydraulic function for loader attachments Hydraulic take-off on excavator for hand-held tools Hydraulic take-off on excavator-mounted tools

Hydraulic take-off on vibrating cable layer Hydraulic take-off on hydraulic post-raiser Extra protection for bucket cylinder Safety belt Warning triangles Rotating warning beacon Adjustable working beams Window washers Fuel filling pump

Hydraulic oil cooler

The manufacturers reserve the right to change specification or design without prior notice. Illustration do not necessarily show the machine in its standard version.



VOLVO BM AB ESKILSTUNA SWEDEN